



Mass Production Upgrade Guide

HF-A11x

Shanghai High-Flying Electronics Technology

TEL: +86-021-31151498

www.hi-flying.com

Copyright © 2013 By Shanghai High-Flying Electronics Technology Co., Ltd. All rights reserved.

The drawings, specifications and the data contained in this document are exclusively the property of Shanghai High-Flying Electronics Technology Co., Ltd. The information is intended for internal use only and is subject to change without any notice.

With no written permission from Shanghai High-Flying Electronics Technology Co., Ltd, this document, in parts or as a whole, shall not be reproduced, copied, or used in any form or by any means to make any derivatives such as translation, transformation, or adaptation, for any purpose whatever is a registered trademark of Shanghai High-Flying Electronics Technology Co., Ltd. Other brands and product names mentioned herein are trademarks or registered trademarks of their respective holders.

HF-A11 Mass Production Upgrade Guide

Note: For the custom firmware, High-Flying provide tools to upgrade the HF-A11 module


A. Upgrade Environment

1. Requests

- (1) HF-A11 EVK: 1
- (2) Computer(Use Ethernet and UART): 1
- (3) High-Flying Upgrade Tool

2. Topology

The topology is as following picture.



B. Software Install and Config

1. Uncompress “HF Production Upgrade Tool(1.09.8)”.

(1) Put upgrade firmware into “config” directory as following “A11_V40211_ZTEKT_kt12_1M_20131126”.

名称	修改日期	类型
script	2014/2/8 18:25	文件夹
A11_V40211_ZTEKT_kt12_1M_20131126	2014/1/24 17:18	文件
mfw.bin	2013/12/9 15:21	BIN 文件
UserConfig.dat	2014/2/8 16:36	PPTV媒体

(2) Enter “config->script” directory, Open config file “A11 和 SMT 通用版本以太网升级.da”.

✓ Modify the firmware file name in “[STEP3]”.

```
[STEP3]
NAME=升级中
ATCMDNUM=2
ATCMD1=HTTPUPG, 1, 50, 1, 10.10.100.100/A11_V40211_ZTEKT_kt12_1M_20131126 +ok
ATCMD2=Z, 1, 10, 0, +ok
```

✓ Modify the setting parameters in [STEP7]. Check the “VER” and “WAP” to make sure upgrade is successful.


```
[STEP7]
NAME=检查参数.....
LOOPNUM=1
ATCMDNUM=2
ATCMD1=VER, 1, 10, 0, +ok, 4.02.11.KT12
ATCMD2=WAP, 1, 10, 0, +ok, 11BGN, MyWiFi, Auto
```

(3) Save the modified file.


2. Install “gtk2-runtime.exe”

“gtk2-runtime.exe” install procedure:


(1) Click and run “gtk2-runtime.exe” and click “NEXT”.




(2) Click "I Agree"




(3) Click "Next".




(4) Click "Next".




(5) Click "Install".



(6) Click "Next".



(7) Click "Finish" to complete installation.




C. Upgrade Process

Note:


(1) Before upgrade, shutdown the firewall and disable the wireless LAN of computer.



(2) modify LAN parameter to IP:10.10.100.254, IP mask:255.255.255.0, gateway: 10.10.100.254.



1. Click  HFProductTools Tool and choose the corresponding serial port



2. Click “开始” to start upgrade, if it finally show “测试成功，请插入新的模块” that the module is upgrade OK and the nReady, nLink LED of EVK is flashing.



3. Power down the EVK, switch to the next module to upgrade the next.